

# LED controller


E6-TD1



Manual

## Product Size

Unit : mm




## Technical Specs

|                     |                                                                                     |
|---------------------|-------------------------------------------------------------------------------------|
| Model               | E6-TD1                                                                              |
| Dimming Mode        | Leading edge (Triac)                                                                |
| Input Voltage       | 220-240Vac, 50/60Hz                                                                 |
| Load Power          | Incandescent lamp or high-voltage halogen lamp : 25W-500W;<br>Dimmable LED: 6W-300W |
| Working Temp.       | -10°C~55°C                                                                          |
| Dimensions(L×W×H)   | 86×86×50mm(L×W×H)                                                                   |
| Package Size(L×W×H) | 106×106×60mm(L×W×H)                                                                 |
| Weight(G.W.)        | 180g                                                                                |

CE RoHS

## Product Images




Dimmer knob




Input

Output

## Wiring Diagram




## Installation Instruction




Dismount

Typical bases are as follow:



European Style



86 Type

## Attentions

- Product installation and commissioning should be done by a qualified professional.
- Products are and not lightningproof non-waterproof (special models excepted). Please avoid the sun and rain. When installed outdoors, please ensure they are mounted in a water proof enclosure or in an area equipped with lightning protection devices .
- Good heat dissipation will prolong the working life of products. Please ensure good ventilation.
- Please check if the working voltage used complies with the parameter requirements of products.
- The diameter of wire used must be able to load the light fixtures you connect and ensure the firm wiring.
- Before you power on products, please make sure all the wiring is correct.
- If a fault occurs, please do not attempt to fix products by yourself. If you have any question, please contact your suppliers.

## Warranty Agreement

- Warranty periods from the date of manufacture: 5 years.
  - Free repair or replacement services for quality problems are provided within warranty periods.
- Warranty exclusions below:

Following conditions are not within the guarantee range of free repairing or replacement services:

- Beyond warranty periods.
  - Any artificial damage caused by high voltage, overload, or improper operations.
  - Products with severe physical damage.
  - Damage caused by natural disasters and force majeure.
  - Warranty labels and barcodes have been damaged.
  - No any contract or invoice signed by our company .
1. Repair or replacement provided is the only remedy for customers. Our company is not liable for any incidental or consequential damage unless it is within the law .
  2. Our company has the right to amend or adjust the terms of this warranty. The warranty that issues in writting shall prevail.
- \* This manual is subject to changes without further notice. Product functions depend on the goods. Please feel free to contact our company or our official distributors if you have any question.